

## ПРИЛОГ 3

### Списак скраћеница коришћених у Правилнику

AFA – Adaptive Frequency Agility  
 AP-MP- Any point-to-Multipoint  
 ATPC- Automatic Transmit Power Control  
 BBDR- Broad Band Disaster Relief  
 BFWA - Broadband Fixed Wireless Access  
 BMA- Building Material Analysis  
 CB - Citizen Band  
 CEPT - European Conference of Postal and Telecommunications Administrations  
 CW- Continuous Wave  
 DAA - Detect And Avoid  
 DEC - Decision  
 DECT - Digital Enhanced Cordless Telecommunication  
 DC - Duty Cycle  
 DSB- Double Side band  
 DSSS – Direct Sequence Spread Spectrum  
 EAS-Electronic Article Surveillance  
 ECA - European Common Allocation  
 ECC - Electronic Communications Committee  
 ERC - European Radiocommunications Committee  
 FDD - Frequency Division Duplex  
 FHSS- Frequency Hopping Spread Spectrum  
 FM - Frequency Modulation  
 FMCW- Frequency Modulation Continuous Wave  
 FSS - Fixed-Satellite Service  
 FWA - Fixed Wireless Access  
 GPR/WPR - Ground Probing Radar/Wall Probing Radar)  
 HEST - High E.i.r.p. Satellite Terminals  
 HF - High Frequency  
 ISM - Industrial, Scientific and Medical  
 ITS - Intelligent Transport Systems  
 ITU - International Telecommunication Union  
 LBT- Listen Before Talk  
 LDC - Low Duty Cycle  
 LEST - Low E.i.r.p. Satellite Terminals  
 LPR - Level Probing Radar  
 PMR - Professional Mobile Radio, Private Mobile Radio  
 PPDR - Public Protection and Disaster Relief  
 P-MP - Point-to-Multipoint  
 PP- Point-to-Point

REC - Recommendation  
RFID - Radio Frequency Identification  
RLANS - Radio Local Area Network System  
RR - ITU Radio Regulations  
RTTT - Road Transport & Traffic Telematics  
SSB- Single Side Band  
SRD - Short Range Device  
SRR - Short Range Radar  
TDD - Time Division Duplex  
TLPR - Tank Level Probing Radar  
TPC- Transmit Power Control  
UWB - Ultra Wideband  
VSAT - Very Small Aperture Terminal  
WAS - Wireless Access System